The button directs the main air flow to the windshield for faster defrosting. It also overrides any MODE selection you may have made.

When you select , the A/C turns on automatically and the system selects Fresh Air mode. For faster defrosting, manually set the fan speed to high. You can also increase air flow to the windshield by closing the side vents in the dashboard.

When you turn off by pressing the button again, the system returns to its former settings.

Rear Window Defogger Button
This button turns the rear window defogger on and off (see page 64).





Climate Control System

Sunlight Sensor/Temperature Sensor





The climate control system has two sensors. A sunlight sensor is located in the top of the dashboard and a temperature sensor is next to the steering column. Do not cover the sensors or spill any liquid on them.